



**HANDY
MOTOR
and
supplied
tools**

**1/16 Allen
7/64 Allen**



**Use the
1/16
Allen
wrench to
remove the
gold knob**





Use the
1/16Allen
wrench to
remove the
black knob



Put motor
assembly
onto
pinion
assembly



First start small pin into the gold knob and then slide clamp onto silver housing, this will most likely be a snug fit using a gentle back and forth motion slide the assembly together.

Slide clamp all the way onto the silver housing



Using the
7/64 Allen
wrench
tighten the
clamping
screw



Make sure the gold knob is centered
in the slot then tighten the gold knob
using the 1/16 Allen wrench





Turn black focus knob to make sure gold knob will not rub on motor housing. If gold knob rubs and you can't fix it by adjusting the gold knob, you can loosen the clamp assembly and move the entire assembly slightly in or out, the gold knob will remain tight to the small shaft.



By turning the round motor housing counterclockwise you will disengage the gears, allowing manual use of the focuser, turn the motor housing clockwise to engage the gear for motor focusing.



You are now ready to operate your new system!!!